


WHAT IS IDA PRO?



- IDA Pro combines an interactive, programmable, multi-processor disassembler coupled to a local and remote debugger and augmented by a complete plugin environment
- IDA Pro is the industry standard for hostile code analysis, vulnerability research, software validation, interactive debugging, and much more



THANK YOU TO THE SCHOOL OF ECE!!




- IDA Pro enables multi-processor disassembly and debugging across more than 50 processor families
- IDA Pro provides a unique advantage to software security research and education
- Simply having IDA Pro experience makes you a top candidate for many careers
 - Malware analyst, low-level software developer, security researcher, ...
- The School of ECE saw the exciting potential of providing students access to IDA Pro
- IDA Pro is not cheap --- A single floating license costs over \$2800 USD!
- The School of ECE has graciously purchased 30 floating licenses for this course!
- We are among a small group of universities which have this educational benefit

HOW TO ACCESS IDA PRO



- IDA Pro is installed in the School of ECE's cloud servers
- Four very powerful Red Hat Linux 7 machines
 - ece-linlabsrv01.ece.gatech.edu
 - 100+ GB memory and 24 cores each!
- IDA Pro runs on those machines, we can connect to the GUI in 2 ways:
 - 1) Standard SSH with X11 forwarding
 - Best on fast internet connections (e.g., on campus)
 - 2) FastX Client
 - Best on slow internet connections





ece-linlabsrv01.ece.gatech.edu

CREATING THE NEXT®

FASTX CLIENT




- FastX is a custom X server & client implementation
 - It is optimized to be more efficient over slow internet connections
 - Standard SSH with X forwarding is terrible over slow connections
- Georgia Tech OIT provides FastX Client for Windows, Linux, and Mac
 - Available at: http://software.oit.gatech.edu
- The IDA Pro Servers are running the custom FastX server
- The FastX Client handles connecting to the IDA Pro Servers and displaying the X11 GUI
- Supported by Georgia Tech OIT ©

DO NOT FORGET TO VPN!



- We can only access these machines through the Georgia Tech VPN!
 - Even on eduroam you need the VPN
 - Only the on-campus ECE computer labs can access them without the VPN


- Georgia Tech OIT provides & supports VPN clients for Linux, Windows, Mac, ...
- https://gatech.service-now.com/home?id=kb_article_view&sysparm_article=KB0026837



LINUX VPN



https://gatech.service-now.com/home?id=kb article view&sysparm article=KB0028027



AFTER VPN, STANDARD SSH WITH X11 FORWARDING



• Be sure to set X11 forwarding on, compression on, and cipher preferences for fast ciphers

~	Terminal - brendan@brendan-laptop: ~ - ▷ 😢
File	Edit View Terminal Tabs Help
bren	dan@brendan-laptop:~\$ ssh -XC bds3@ece-linlabsrv01.ece.gatech.edu
٠	ece-linlabsrv01.ece.gatech.edu
٠	100+ GB memory and 24 cores each!
IDA	Pro runs on those machines, we can connect to the GUI in
1)	Standard SSH with X11 forwarding
1)	Standard 5511 With A11 for warding
	Best on fast internet connections (e.g., on campus)
2)	FastX Client

ENTER PASSWORD AND YOU'RE CONNECTED!




Terminal - brendan@brendan-laptop: ~ File Edit View Terminal Tabs Help Now you have a terminal orendan@brendan=laptopr=\$\ssh -XC bds3@ece-linlabsrv01.ece.gatech.edu with X11 forwarding from This computer system is the property of the Georgia Institute of Technology. Any user of this system must comply with all Institute and Board of Regents policies, including the Acceptable Use Policy, Cyber Security Policy and ece-linlabsrv01.ece.gatech.edu Data Privacy Policy (http://b.gatech.edu/it-policies). Users should have no expectation of privacy, as any and all files on this system may be intercepted, monitored, recorded, copied, inspected, and/or disclosed to authorized personnel in order to meet Institute obligations. By using this system, I acknowledge and consent to these terms. bds3@ece-linlabsrv01.ece.gatech.edu's password: Terminal - brendan@brendan-laptop: ~ File Edit View Terminal Tabs Help login session at the discretion of the CSG. bFlagrantaggio or repeated violationsemayeineextreme cases bendan@ece.gatech... subject to suspension or revocation of account privileges. Jobs running for longer than 5 days on the ecelinsry systems will be automatically terminated at the discretion of the CSG. If you need to run substantially long jobs, email help@ece requesting a PACE account. If you are having problems running applications, see http://www.ece-help.gatech.edu/unix/cshrc.html for information on configuring your login environment. bds3@ece-linlabsrv01.ece.gatech.edu> bds3@ece-linlabsrv01.ece.gatech.edu> bds3@ece-linlabsrv01.ece.gatech.edu>

CREATING THE NEXT®

bds3@ece-linlabsrv01.ece.gatech.edu> bds3@ece-linlabsrv01.ece.gatech.edu>




- SSH with X forwarding is <u>terrible</u> over slow connections
- FastX is optimized for slow connections
 - Also, Georgia Tech OIT will always recommend that you use FastX
- Download FastX from GT OIT
 - http://software.oit.gatech.edu
- 2. Extract the tar.gz file
- 3. cd to the extracted FastX directory
- 4. Execute: \$ PATH=\$PATH:./ ./FastX
- There is a BUG in the Linux FastX client!
- It needs the FastX directory in the PATH to correctly find its dependencies!




CREATING THE NEXT®




















https://gatech.service-now.com/home?id=kb article view&sysparm article=KB0026742




AFTER VPN, WINDOWS FASTX CLIENT






LAUNCH APPS IN FASTX





LAUNCH APPS IN FASTX









ONCE YOU ARE CONNECTED TO THE IDA PRO SERVERS...

YOU ARE IN ECE TERRITORY!
ALL PROBLEMS MUST BE SENT TO:
HELP@ECE.GATECH.EDU

CREATING THE NEXT®

IDA PRO ENVIRONMENT



- · Before you can do anything with IDA Pro, you must first set up the running environment
- Use the following command: \$ source /tools/software/hex-rays/idapro.csh
- Note: You may not see the /tools/software/hex-rays/ directory until you execute that command
 - It is our "secret" key!
- Only needs to be done once (per terminal) to set up the environment

- Everything related to IDA Pro is available in /tools/software/hex-rays/
 - We have read & execute permissions in that folder (after executing "\$ source ...")
- Feel free to look through the directories, read the docs, and check out the SDK!

A TALE OF TWO IDAS



- IDA Pro has two different executables
 - Which executable you use depends on what binary you are analyzing
- ida for working with 32-bit binaries
- ida64 for working with 64-bit binaries
- You will get an error if you use the wrong one
- I recommend executing them with "&" after to put the process in the background

NOTICE THE TCSH!



- The default shell on the ECE machines should be /bin/tcsh
- THIS IS NOT BASH! But it is similar
 - https://help.ece.gatech.edu/linux/shells
- The "\$ source /tools/software/hex-rays/idapro.csh" command will ONLY work in tcsh!
- You can check your current shell with "echo \$0"
- After you run "\$ source ..." you can switch to /bin/bash if you want

```
bds3@ecelinsrvw.ece.gatech.edu>
bds3@ecelinsrvw.ece.gatech.edu>
bds3@ecelinsrvw.ece.gatech.edu>echo $0
/bin/tcsh
bds3@ecelinsrvw.ece.gatech.edu>source /tools/idapro/ida-
bds3@ecelinsrvw.ece.gatech.edu>/bin/bash
[bds3@ecelinsrvw ~]$ ida &
[1] 44579
[bds3@ecelinsrvw ~]$
[1]+ Exit 1
                              ida
[bds3@ecelinsrvw ~]$ ida64 &
[1] 44602
[bds3@ecelinsrvw ~]$
[1]+ Exit 1
                              ida64
[bds3@ecelinsrvw ~]$
```

G THE NEXT'S

CLOUD IDA



- Notice that IDA Pro will be executing on the remote server
- So you have to move any files/test cases/etc. to your home directory before you begin
- You also need to pull your answers/submission filed back down when you're finished
- Many remote file copy utilities exist for every platform
- On Linux, use the scp command:
 - Please see this helpful cheat-sheet for a range of scp uses:
 http://www.hypexr.org/linux-scp-help.php


WINSCP FOR THOSE WHO LIKE GUIS



SFTP-3


- Another great option on Windows is WinSCP
- Download from: https://winscp.net/eng/download.php
- The exact same source code as SCP, just wrapped in a Windows GUI

 Simply drag and drop files between the two machines ©



SIGNING INTO WINSCP






- Protocol = SFTP
- Fill in the host name and username fields
- Port = 22
- Remember to save!
- Give the session a nice name

Save session as site	?	×				
Site name:						
bds3@ece-linlabsrv01.ece.gatech.edu						
Folder:						
<none></none>		~				
Save password (not recommended)						
OK Cancel	<u>H</u> e	elp				

ENTER PASSWORD & YOU'RE ALL SET!







SELECT YOUR ANALYSIS TARGET!



• When IDA Pro starts it will ask you to start a new disassembly or open a previous one





LOADING A NEW FILE



File Edit Jump Coords View Ontions Windows Help	IDA v6.95.160808	- + X
File Edit Jump Search View Options Windows Help		
File Eat Jump Search View Options Windows Help File Eat Jump Search View Options Windows Help A	Select file to disassemble Look in: Inethome/bds3/homeworks Computer Name Size Type Date Modified 8 KB File 8/26/17 4:41 PM	
	File name: Open	
	Files of type: All known file extensions (*) ▼ Cancel	
Output window		
Python		
@:00000000000000 Down		
С.00000000000000 ДОМП		

IDA WILL THEN ASK FOR LOADING INSTRUCTIONS



CREATING THE NEXT®


The defaults are almost always correct ... unless you are dealing with nasty malware!

	IDA v6.95.160808	- + ×
Eile Edit Jump Search View Options Windows Help		
ie gat lump search view options windows help ie at lump search vie	Load a new file Load file /nethome/bds3/homeworks/hello as ELF64 for x86-64 (Executable) [elf64.llx64] Dinary file Processor type MetaPC (disassemble all opcodes) [metapc] Analysis Loading segment	
	Load as code segment	
0utput window	OK Cancel Help	
bytes pages size description 262144 32 8192 allocating memory for b-tree 65536 8 8192 allocating memory for virtual array 262144 32 8192 allocating memory for name pointers 589824 total memory allocated Loading processor module /tools/idapro/ida-695/procs/pc64.ilx64 for metapc Autoanalysis subsystem has been initialized Possible file format: ELF64 for x86-64 (Executable) (/tools/idapro/ida-695/location)		
Python		
@:0000000000000 Down		

IDA WILL OPEN IN CONTROL FLOW GRAPH VIEW




Right-click and select Text View to view the flat disassembled code



COMMENTS: RIGHT-CLICK -> ENTER COMMENTS (OR PRESS ":")





PRO TIP: RENAME LABELS AS YOU GO!



```
text:0000000000400526
                                        push
                                                 rbp
text:0000000000400527
                                                 rbp, rsp
                                        mov
text:000000000040052A
                                        sub
                                                 rsp, 10h
text:000000000040052E
                                        mov
                                                 [rbp+var_4], edi
text:0000000000400531
                                        mov
                                                 [rbp+var_10], rsi
text:0000000000400535
                                        cmp
                                                 [rbp+var_4], 2
                                                 short loc 400558
text:0000000000400539
                                        jnz
text:000000000040053B
                                        mov
                                                 rax, [rbp+var 10]
text:000000000040053F
                                        add
                                                 rax, 8
text:0000000000400543
                                        mov
                                                 rax, [rax]
text:0000000000400546
                                        mov
                                                 rsi, rax
text:0000000000400549
                                        mov
                                                 edi, offset format
                                                                       "Hello %s\n"
text:000000000040054E
                                        mov
                                                 eax, 0
text:0000000000400553
                                        call
                                                 printf
text:0000000000400558
                                                                  ; CODE XREF: main+13|1
text:0000000000400558
                       loc 400558:
text:0000000000400558
                                        mov
                                                 eax, 0
text:000000000040055D
                                        leave
text:000000000040055E
                                        retn
text:000000000040055E main
                                        endp
text:000000000040055E
t aut : 000000000000.0055B
```

- 1. Click on the element to rename
- 2. Press the "n" key
- 3. Enter name and settings (if any)
- 4. Enjoy easier to read assembly!

```
text:000000000040052A
text:000000000040052E
text:0000000000400531
text:0000000000400535
text:0000000000400539
text:000000000040053B
text:000000000040053F
text:0000000000400543
text:0000000000400546
text:0000000000400549
text:000000000040054E
text:0000000000400553
text:0000000000400558
text:0000000000400558
text:0000000000400558
text:000000000040055D
text:000000000040055E
text:000000000040055E
```

mov

mov

call

mov

leave

retn

endp

```
Rename address
                                                   ×
   Address: 0x400558
          QUIT
                                             ₩
   Maximum length of new names
                                    15
   Local name prefix
                                    @@
            ✓ Local name
           ☐ Include in names list
           Public name

    Autogenerated name

           Weak name
            Create name anyway
             0<u>K</u>
                          Cancel
                                         Help
         тыр, тар
          rsp, 10h
mov
          [rbp+var_4], edi
mov
          [rbp+var_10], rsi
cmp
          [rbp+var_4], 2
jnz
          short QUIT
mov
         rax, [rbp+var_10]
add
mov
         rax, [rax]
mov
         rsi, rax
```

```
CREATING THE NEXT®
```

"Hello %s\n"

CODE XREF: main+13| j

edi, offset format

eax, 0

eax, 0


printf

PRO TIP #2: SWITCH BETWEEN VIEWS!

Text View may be easier to read, but Graph View gives better context




Comments still show in both views ©



PRO TIP #3: NAVIGATION BUTTONS!

Georgia
ers! Tech

Double-click on a label to jump to it. Want to go back? IDA remembers!



PRO TIP #4: RENAME SYMBOLIC CONSTANTS



- IDA's FLIRT signatures know the arguments for common APIs
- But IDA also knows the symbolic names for most defined constants!
- You just have to tell IDA what value you are looking for


```
LONG WINAPI RegCreateKeyEx (
                                   hKey,
  In
             HKEY
             LPCTSTR
                                   lpSubKey,
                                   Reserved,
  Reserved DWORD
   In opt
             LPTSTR
                                   lpClass,
                                   dwOptions,
             DWORD
  In
           REGSAM
                                   samDesired,
   In
  In_opt_ LPSECURITY_ATTRIBUTES lpSecurityAttributes,
             PHKEY
                                   phkResult,
  Out
                                   lpdwDisposition
  Out opt
             LPDWORD
```

```
[ebp+phkResult]
lea
                           lpdwDisposition
push
        ecx
                          phkResult
push
        eax
                           1pSecurityAttributes
push
        ecz
                           samDesired
push
        OFOO3Fh
push
                           dwOptions
        ecx
push
                           lpClass
        ecx
push
        ecz
        offset aSoftwareMicr 1 ; "Software\\Microsoft\\Windows\\CurrentVe"...
push
push
        80000002h
                         ; hKev
call
        ebx ; RegCreateKeyExA
```

PRO TIP #4: RENAME SYMBOLIC CONSTANTS (2)

- Right Click -> Use standard symbolic constant
- Then simply find the constant name you are looking for





 Second, read about adding new Enums and symbolic constants here: https://www.hex-rays.com/products/ida/support/idadoc/499.shtml


First, look up the symbol's header file definition

CREATING THE NEXT®

SAVE OFTEN!




- Losing hours of reverse engineering can be hazardous to your health!
- CTRL-W !!



EXPORT YOUR ASSEMBLY LISTING




- IDA can export all the Text View content to a "Listing" file
 - You will often turn these in for reverse engineering assignments



READY TO CLOSE IDA? SAVE YOUR DATABASE (OR NOT)



- IDA will compress all of its data into a single database to save your progress
 - The save file is called an idb file for 32-bit and i64 for 64-bit
- You can also tell IDA to not save a database (i.e., you lose everything you've done)



AS YOU WORK, SO DOES IDA



- IDA performs very substantial analysis for you and saves the results in a number of files while you work
- If you kill IDA (or lose connection to the IDA servers), these files will be corrupted!
- So save often!! Saving will create/update the database file

```
File Edit View Search Terminal Help
bds3@ecelinsrvw.ece.gatech.edu>cd homeworks/
bds3@ecelinsrvw.ece.gatech.edu>ls
hello hello.id0 hello.id1 hello.id2 hello.nam hello.til
bds3@ecelinsrvw.ece.gatech.edu>
                                      idaq64
      Done
[1]
bds3@ecelinsrvw.ece.gatech.edu>ls
hello hello.i64
bds3@ecelinsrvw.ece.gatech.edu>
```

ADDITIONAL READINGS (OPTIONAL)



- Chris Eagle. <u>The IDA Pro Book</u>. No Starch Press (2nd Edition), 2011.
 ISBN: 978-1593272890
 - You can probably find the PDF version online!
- Guided Hacking's "How To Reverse Engineer" Videos
 - https://www.youtube.com/playlist?list=PLt9cUwGw6CYFXtAElzDLob2aOaSfZqHJc

CREATING THE NEXT®

